



**OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.  
IMPORTANT OWNER-OPERATOR INSTALLATION  
INSTRUCTIONS**

**A7714**

**Warning!! Improper installation may result in  
battery over-charging**

**This kit is intended to be combined with the additional  
solar panel kit (A7713) and is for installations with two  
10w [solar panels](#) and four or more batteries.**

**For Installations with two solar panels and 3  
batteries or less, use part number A7715 instead**

## Parts included in this kit:

<b>2x</b>		<b>Black Zip Ties</b>
<b>1x</b>		<b>Y-Harness</b>

### **Step 1 : - Y-Harness Adapter**

If your first panel is already installed on the Power Armor Lid,

remove the **Phillips Pan Head #8 x 3/8" Sheet Metal Screws** to gain access to the bottom of the **10 Watt Solar Panel**.

Connect the female SAE connectors of the **Y-Harness Adapter** to the male SAE connectors on each of the **10 Watt Solar Panels**. Rest the **10 Watt Solar Panels** on top of the Power Armor Lid. The Male end of the **Y-Harness adapter** should stick out approximately 6 inches from the left side of the Power Armor. Any extra wire can be coiled up and zip tied underneath the **10 Watt Solar Panels**.

For Power Armor Solar or Additional 10W Solar Panel instructions, refer to the instructions supplied with those parts.

**All solar parts are warranted through Zamp Solar.**