

Attach mount clamp by turning the C-Clamp knob; adjust the clamp bracket position if necessary with a Phillips screwdriver. Slide optional rubber clamp boot onto the top of the mount's clamp to prevent scratching clamp surface if desired.




2 Attach tablet holder the the mount.





IMPORTANT: The Slim-Grip Universal Tablet Holder fits all tablets with 8.9" - 18.4" screen size. It includes 4 short, 2 medium, and 4 long support legs. Select a combination of 4 support legs in conjunction for use with the spring-loaded holder to achieve the perfect fit for your tablet.

3 Insert tablet.







Safety Precautions
Do not install Arkon products over an air bag cover or an air bag deployment zone. Arkon
Resources, Inc. is not responsible and assumes no liability for injury or death as a result of

Arkon is not responsible for any damages caused to your device or yourself due to the installation or use of this product.