



Package Contents:

- (1) RV001WR-B – RoadVise™ Universal Smartphone Holder
- (1) TAB001 – Slim-Grip® Universal Tablet Holder
- (1) APEQUIPXL – Metal Equipment Mounting Plate
- (1) SPHD8BASE – Weighted Base for HD008 Pedestal
- (1) SPHD8L29 – 29" Shaft for HD008 Pedestal
- (1) AP20MMAL – 4-Hole AMP5 to 20mm Ball Adapter
- (2) APAMPS17MM – 4-Hole AMP5 to 17mm Ball Adapter
- (1) APAMPS22MM – 4-Hole AMP5 to 22mm Ball Adapter
- (1) SP-SB-RING-22 – Tightening Ring for 22mm Ball
- (1) SP-SB-2T-22 – Dual-T Head for 22mm Ball
- (3) SP-12M-4M7 – Screw Pack

NOTE: Tablet and dual phone stand is ideal for iPhone/smartphone and tablet live streaming.


NOTE: Arkon's RoadVise™ Universal Holder fits phones up to 4" wide.

NOTE: The Slim-Grip® Universal Tablet Holder fits all tablets with 8.9" – 18.4" screen size. Select a combination of 4 support legs in conjunction for use with the spring-loaded holder to achieve the perfect fit for your tablet. For midsize tablets, use 2 short legs on top and 4 large legs on bottom; for full-size tablets, use 2 short legs on top and 2 medium legs on bottom.

Connecting Telescoping Arm:


Insert telescoping arm tube into weighted base. You will need to use some force as this will be a tight fit. Tighten base lock to secure with included Allen wrench. Adjust the height and angle of the pedestal by loosening the adjustment ring and the adjustment knob. Retighten to set.

SAFETY PRECAUTION: Failing to properly secure the base to the shaft could cause bodily injury or harm. Always use two hands (one on shaft, and one on base) when carrying.




Adjusting Weighted Base:

Adjust the height and angle of the mount by loosening the adjustment ring and the adjustment knob. Retighten to set.




Disconnecting Shaft:

Disconnect the shaft from the plate sliding the Dual T-Tabs of adapter from the Dual T-Slots of the plate.




Inserting Tablet:

Insert device into holder by pushing down on the bottom spring-loaded support legs with the device. Slide the top of the device under the top support legs until it fits snugly in the holder.



Inserting Phone:

Using two hands, insert phone into the holder by pushing the device into one of the spring-loaded legs. Expand the other leg and fully insert device until it lays flat against the blue rubber pad.



! Safety Precautions
 Arkon is not responsible for any damages caused to your devices or yourself due to the installation or use of this product.
 Failing to properly secure the base to the shaft could cause bodily injury or harm. Always use two hands (one on shaft, and one on base) when carrying.



The Mobile Mounting Specialists™