



Model TH100 697.68257

For the home: Mount track to wall or door with 1" screws provided. For hollow walls or doors, use appropriate anchors.





Patio & Garden