



Instruction Manual

TAC-400/410/450/460

THANK YOU FOR SELECTING THE NIGHTSTICK TAC!
PLEASE SAVE THESE INSTRUCTIONS

Please read these instructions before using your TAC. They include important safety and operation information. Be sure to charge the TAC fully before the first use. A battery is fully charged when the charger light is green.



Included in the box - Compris dans la boîte - Includido en la caja

WARNINGS

- Lithium-ion batteries must be used and charged properly. Improper use can result in serious injury, fire, or death.
- NOT FOR USE IN HAZARDOUS LOCATIONS. Do not use this product in explosive atmospheres, near flammable liquids, or where explosion proof or intrinsically safe lighting is required.
- DO NOT use this product in the proximity of vehicles or equipment when there is a risk of flammable liquids coming into contact with the flashlight.
- Light can become hot while on. To prevent damage DO NOT cover or place next to any potentially flammable materials while in use.
- Do not leave the battery in direct sunlight or use or store the battery inside cars in hot weather.
- Do not expose the battery to water or salt water, or allow the battery to get wet.
- Do not store the battery with metallic objects that may cause a short circuit.
- Immediately discontinue use of the battery if the battery emits an unusual smell, feels hot, changes color, changes shape or appears abnormal in any way.
- Keep out of the reach of children.

INITIAL USE

- Fully charge the TAC before the first use, or if the battery is new or has been unused for several months. The maximum charge time required is approximately 4 hours.

DAILY USE

- Use only the supplied Nightstick charger, battery and AC or DC adapter. For best performance, charge the TAC when the flashlight beam starts to dim.
- Connect the AC power adapter to the charger. The LED indicator will not be illuminated at this point.
- With the flashlight facing forward, slide the TAC into the charger until the contacts snap into place.
- The LED indicator changes to constant red indicating the TAC is properly inserted into the charger and is in fact charging. The LED indicator remains red until the battery is fully charged. At full charge, the LED indicator turns green.
- The total time to full charge the TAC varies depending on the remaining charge in the battery pack.
- To confirm a full charge, keep the TAC in the charger and turn it on. The LED indicator will change to red. Turn off the TAC. If the TAC is fully charged, the LED indicator will turn green. If not, it remains red until the charge is completed and the LED indicator turns green. The TAC will now be fully charged.

OPERATION

The TAC has two light modes: momentary flashlight and constant-on flashlight. The TAC has a single tail switch providing access to all modes.

MOMENTARY FLASHLIGHT MODE

Lightly press the tail switch for momentary operation. Release the switch to turn the light off.

CONSTANT-ON

Press the tail switch until it clicks and then release for constant-on mode. Press and release the tail switch again to turn the light off.

CR-123 BATTERY CARRIER

The CR123 battery carrier converts the TAC from rechargeable Lithium-ion to non-rechargeable Lithium battery operation.



Load two CR-123 Lithium batteries with the positive terminals pointing in the direction of the arrow. NOTE: The flashlight cannot be charged with the CR-123 CARRIER installed.

BAYCO PRODUCTS LIMITED LIFETIME WARRANTY

WARRANTY

Bayco Products, Inc. warrants this product to be free from defects in workmanship and materials for the original purchaser's lifetime. The Limited Lifetime Warranty includes the LEDs, housing and lenses. Rechargeable batteries, chargers, switches, electronics and included accessories are warranted for a period of two years with proof of purchase. Disposable, non-rechargeable batteries are excluded from this warranty. Normal wear and failures which are caused by accidents, misuse, abuse, faulty installation and lightning damage are also excluded.

In the event that Bayco Products, Inc. receives notice that any product does not conform to its warranty, the original purchaser's sole and exclusive remedy, and Bayco Products, Inc.'s sole and exclusive liability, shall be

for Bayco Products, Inc., at its sole option, to either repair or replace the non-conforming product in accordance with this limited warranty. The original purchaser shall follow the instructions below to qualify for a repair or replacement product. This is the only warranty, expressed or implied, including any warranty of merchantability or fitness for a particular purpose.

IN NO EVENT WILL BAYCO PRODUCTS, INC. OR ITS AFFILIATES OR SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND REGARDLESS OF THE FORM OF ACTION, WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE. THE TOTAL CUMULATIVE LIABILITY TO CUSTOMER, FROM ALL CAUSES OF ACTION AND ALL THEORIES OF LIABILITY, WILL BE LIMITED TO AND WILL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT PAID BY CUSTOMER.

If this product is used for rental purposes, the warranty term is reduced to 90 days from the date of purchase.

WARRANTY CLAIMS – USA

Return the product to the place of purchase for all warranty related issues. If this is not possible, contact Bayco Customer Service for a Return Goods Authorization (RGA). Do not return this product to Bayco without first receiving an RGA Number from Bayco Customer Service. When returning the product, the RGA Number must be written on the outside of the shipping box.

WARRANTY CLAIMS – OUTSIDE OF USA

Return the product to the place where purchased for all warranty related issues.

EXTENT OF COVERED WARRANTY WORK

Bayco will repair or replace this product at our option. If it is determined that the warranty is no longer in effect, Bayco will contact you with a repair estimate before beginning any work.

WARRANTY QUESTIONS

If you have any questions about this warranty or any other Bayco product inquiries, please contact Bayco Customer Service.