



CARE INSTRUCTIONS



CARE & MAINTENANCE INSTRUCTIONS

For long lasting durability and the best possible protection for your E-Z UP® Instant Shelter® products, follow these E-Z care and maintenance instructions:

For Everyday Use and Storage:

- Always use an E-Z UP Roller Bag or E-Z UP Cover Bag for protection during storage or transportation.
- Although the top is designed to remain on the frame during storage, let the top and frame dry completely before closing or storing to avoid mildew.
- Use E-Z UP Weight Bags or E-Z UP Stakes to secure your shelter when set up and in-use as windy conditions can arise at any time.

For Cleaning and Maintenance:

- Use a mild soap (not detergent) and plenty of water to clean your E-Z UP® top.
- Frame will operate and look better if occasionally treated with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top.
- Use a seam sealer (available at most sporting goods and hardware stores) if top leaks or drips water.
- Hand tighten bolts if frame becomes loose (do not over tighten as this can result in broken trusses).