



1 Place folded cot on ground like shown.




2 Unfold cot rails by swinging them outward.

3 Pull upward on cot rails to deploy legs.

4 Place cot upright on the ground.



5 Engage both leg locks located along the rails.



6 Reverse steps to collapse cot.

FURNITURE CARE

- Weight limit: 300lbs
- Keep away from open flame
- Use on level ground
- Use caution to avoid injuring fingers when opening/closing

WARRANTY

- Your Eureka! furniture is covered by a one year warranty.