



Pet Life Jacket Sizing Guide

PART NUMBER	SIZE	WEIGHT		LENGTH		NECK GIRTH		BODY GIRTH	
		LBS	Kg	IN	CM	IN	СМ	IN	СМ
1100	xxs	0-6	0-3	6.5	17	7-9	18-23	11-16	28-41
1200	xs	7-15	3-7	8.5	22	8-12	20-31	15-19	38-48
1300	S	15-20	7-9	11	28	12-20	31-51	17-22	43-56
1400	M	20-50	9-23	14	36	20-25	50-62	21-30	53-76
1500	L	50-90	23-40	16	41	24-30	60-76	30-37	76-94
1600	XL	90+	40+	20	51	29-34	72-87	36-44	92-112



Measure Pet Length

Measure from the base of the neck to the base of the tail. Keep in mind the jacket will not completely cover long-bodied dogs (corgi, dachshund, etc) which is acceptable as the main girth of the dog will be supported.



Measure Pet Body Girth

Measure the widest part of the ribcage keeping in mind the pet life jacket should be form fitting like a human life jacket to provide proper flotation.



Measure Pet Neck Girth

Measure the widest part of their neck keeping in mind the pet life jacket should be form fitting but not restrict breathing.