

## RAINWEAR SIZE GUIDE

Men's					
Size	Chest	Waist	Sleeve	Inseam	Height
S	38-40	30-34	35 ½	30	4'8"-5'4"
M	42-44	34-38	36 ½	31 ½	5'2"-5'10"
L	46-48	38-42	37 ½	33	5'6"-6'3"
XL	50-52	42-46	38 ½	34	5'10"-6'5"
2X	54-56	46-50	39 ½	35	6'0"-6'8"
3X	58-60	50-54	40 ½	36	6'2"-6'10"

Women's					Kid's
Size	Chest	Waist	Sleeve	Inseam	Size
S (6-8)	32-34	25-27	32 ½	31 ½	S (4)
M (8-10)	34-36 ½	27-29 ½	33	31 ½	M (8)
L (10-12)	37-39 ½	30-32 ½	33 ½	31 ½	L (12)
XL (12-14)	40 ½-43 ½	33-35 ½	34	32	
2X (14-16)	44 ½-47 ½	36-39 ½	34 ½	32	

**Chest:** With arms relaxed at sides, measure around the largest part of the chest and shoulder blades

**Sleeves:** Measure from the center back at neck base along shoulder and down arm to wrist with a slightly bent elbow.

**Waist:** Measure around waist at its narrowest point.

**Inseam:** Measure from base of crotch down inside of leg to desired pant length.

## WADERS SIZE CHARTS

Breathable Stockingfoot Chest Waders Men's Sizes Pilot II, Anura, Hellbender, Sierra & Canyon			
Size	Foot Size	Max Inseam	Max Chest
SM	6-8	34	45
MD	8.5-11	36	48
MD Stout	8.5-11	36	53
LG	10-12	38	51
LG Stout	10-12	38	56
XL	11-13	38.5	54
XL Stout	11-13	38.5	60
2X	13-15	39	58
2X Stout	13-15	39	65

Women's Sizes Hellbender			
Size	Foot Size	Max Inseam	Max Chest
SM	7-9	31-33	40
MD	8-10	32-34	43
LG	8-10	33-35	45
XL	9.5-11	33-35	50

Neoprene Stockingfoot Waders Amphib			
Size	Foot Size	Max Inseam	Max Chest
SM	6-8	29	38
MD	8.5-11	30.5	40
LG	10-12	32	42
XL	11-13	33.5	44
2X	13-15	35	45

Breathable Stockingfoot Guide Pants					
Shoe Size	Max Inseam			Waist	
	Pilot II	Hellbender	Pilot II	Hellbender	
SM	6-8	33.75	34	45.5	43
MD	8.5-11	35.5	35.75	48	47.5
LG	10-12	37	37.25	51	51.5
XL	11-13	38.25	38.5	54	57
2X	13-15	39	39	58	60

Breathable Stockingfoot Chest Waders Hellbender			
Size	Foot Size	Max Inseam	Max Chest
SM	6-8	34	45
MD	8.5-11	36	48
LG	10-12	38	51
XL	11-13	38.5	54
2X	13-15	39	58

Neoprene Bootfit Waders Amphib, BullTogg & MarshTogg			
Size	Foot Size	Max Inseam	Max Chest
7	7	33	42
8	8	33	42
9	9	33	44
10	10	35	47
11	11	36	49
12	12	36	49
13	13	36	51
14	14	36	51

Neoprene Bootfoot Waders Amphib			
Size	Foot Size	Max Inseam	Max Chest
7	7	33	42
8	8	33	42
9	9	33	44
10	10	35	47
11	11	36	49
12	12	36	49
13	13	36	51
14	14	36	51

PVC & Rubber Bootfoot Waders Rana II & Cascades			
Size	Foot Size	Max Inseam	Max Chest
7	7	35	50
8	8	36	51
9	9	36	52
10	10	37	53
11	11	37	55
12	12	38	56
13	13	38	56
14	14	38	56

Breathable Bootfoot Waders Hellbender			
Size	Foot Size	Max Inseam	Max Chest
7	7	30	45.5
8	8	31	48
9	9	36	48
10	10	38	51
11	11	38	51
12	12	38.5	54
13	13	39	58
14	14	39	58

PVC & Rubber Bootfoot Waders Rana II & BoggTogg			
Size	Foot Size	Max Inseam	Max Chest
7	7	35	50
8	8	36	51
9	9	36	52
10	10	37	53
11	11	37	55
12	12	38	56
13	13	38	56
14	14	38	56

Breathable Bootfoot Waders Hellbender, Refuge			
Size	Foot Size	Max Inseam	Max Chest
7	7	30	45.5
8	8	31	48
9	9	36	48
10	10	38	51
11	11	38	51
12	12	38.5	54
13	13	39	58
14	14	39	58

## YOUTH WADERS SIZE CHART

Youth Size Hellbender			
Size	Foot Size	Max Inseam	Max Chest
SM	3-4	29	34
MD	4-5	30	36
LG	5-6	32	38