


Please read and save these instructions. Read through this owner’s manual carefully before using product. Protect yourself and others by observing all safety information, warnings, and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.



**SEARCH AND RESCUE SERIES
E81 RECHARGEABLE FLASHLIGHT**

UNPACKING

After unpacking, inspect carefully for any damage that may have occurred during transit. Check for loose, missing, or damaged parts. If any damage is observed, a shipping damage claim must be filed with carrier. Do not use the flashlight if it appears damaged in any way, operates abnormally or is missing parts.



⚠ WARNING

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

The following safety information is provided as guidelines to help you operate your flashlight under the safest possible conditions. Any tool or piece of equipment can be potentially dangerous to use when safety or safe handling instructions are not known or not followed. The following safety instructions are to provide the user with the information necessary for safe use and operation. Please read and retain these instructions for the continued safe use of your flashlight. Failure to follow instructions listed below may result in serious injury. In addition, make certain that anyone that uses the equipment understands and follows these safety instructions as well.



SEARCH AND RESCUE SERIES E81 RECHARGEABLE FLASHLIGHT

Thank you very much for choosing a GreatLite Product!

For future reference, please complete the owner's record below:

Model: _____ **Purchase Date:** _____

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it. We strongly recommend this flashlight is not modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the flashlight until you have first contacted GreatLite to determine if it can or should be performed on the product.

IMPORTANT INSTRUCTIONS AND SAFETY RULES

1. Know your flashlight. Read this manual carefully. Learn the flashlight's applications and limitations, as well as, potential hazards specific to it.
2. Keep work area clean and well lit. Cluttered or dark work areas invite accidents.
3. Keep children away. All children should be kept away from the work area. Never let a child handle

a tool without strict adult supervision.

4. Use safety equipment. Eye protection should be worn at all times when working this tool. Use ANSI approved safety glasses. Everyday eyeglasses are NOT safety glasses. Dust mask, non-skid safety shoes, hard hat, or hearing protection should be used in appropriate conditions.
5. Always disconnect the tool from the power source before making any adjustments, storing, servicing, or changing accessories. Such preventative safety measures reduces the risk of starting the tool accidentally.
6. Do not use the flashlight if the switch does not turn it on and off. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
7. Check for damage. Check your flashlight and batteries regularly. If part of the flashlight is damaged it should be carefully inspected to make sure that it can perform its intended function correctly. If in doubt, the part should be repaired or replaced.
8. Keep away from flammables. Do not attempt to operate this flashlight near flammable materials or combustibles. Failure to comply may cause serious injury or death.

PRODUCT SPECIFICATIONS

	Mode	50%	25%	Flash	SOS
Output	500 Lumens	250 Lumens	125 Lumens	/	/
Runtime	3 Hr	6 Hr	12 Hr	12 Hr	12 Hr
Beam Distance	200 M/656 Ft.				
Impact Resistance	1.5 M/4.9 Ft.				
Water-proof Grade	IPX-8				
Accessories	(1) Li-on Charging Unit, (1) 18650 Battery, Belt Pouch, Lanyard				

PART SPECIFIC INSTRUCTIONS

- Uses Cree XM-L (T6) LED bulb, service life is 100,000 hours
- Uses (2) 3V CR123A Li batteries or (1) 18650 Li-ion battery
- Size: 160 mm (Length) x 27 mm (Diameter) x 50 mm (Head)
- Net weight 224.5 g (0.494 Lb.) (excluding battery)
- Constant current circuit, constant brightness
- Anti-reverse design prevents the damage to circuit caused by reverse loading of battery
- Non-slip design body
- Made out of aircraft aluminum
- Surface anti-wear treatment is done by using hard anodizing
- Uses anti-reflection tempered glass lens




**SEARCH AND RESCUE SERIES
E81 RECHARGEABLE FLASHLIGHT**

OPERATING INSTRUCTIONS

- Basic operation: Slightly touch the tail switch to turn on the flashlight. Press down the tail switch to open the flashlight.
- One rotation makes 100% luminance, a second rotation makes 50% luminance, one more rotation makes 25% luminance, one more rotation makes SOS and a last rotation makes flash mode.

BATTERY REPLACEMENT

1. Screw off the tail and install the battery. Note that the positive pole of the battery shall align with the head, and then screw down the tail. Uses (2) 3V CR123A Li batteries or (1) 3.7V 18650 Li-ion battery.



(1) 18650 Li-ion battery will fully recharge in 6 to 8 hours. At 100% power you should have a fully charged beam for up to 3 hours.

USE AND MAINTENANCE

- Please do not dismantle the sealing parts at the head, otherwise, it will lead to invalid repair and even destroy the flashlight.
- Please use quality batteries only. When the flashlight is not to be used for a long period of time, take out the battery, otherwise, the flashlight may be destroyed due to leakage or explosion of poor quality batteries.
- After a long period of use, the o-ring of the flashlight may wear out. In this case, please replace the o-ring to maintain the water-proof performance of the flashlight.
- Frequently clean the flashlight surface, particularly the tail switch.
- If the flashlight flashes abnormally or does not come on, it may be caused by the following:
 - Reason 1: Low battery power.
Solution: Replace the battery (note positive and negative poles when installing the new batteries.)
 - Reason 2: The conduction contact surface or other contact surface/point of the thread or the PCB is dirty.
Solution: Use alcohol cotton swabs to clean the conduction contact surface or point.

If the above methods do not work, please contact GreatLite customer service.



**SEARCH AND RESCUE SERIES
E81 RECHARGEABLE FLASHLIGHT**

Figure	Description	Quantity
A	500 Lumen E81 Flashlight	1
B	Charging Unit	1
C	3.7 18650 Li-ion Battery	1
D	Belt Pouch	1
E	Spare Water Proof Hat	1
F	Spare O-Rings	1
G	Lanyard	1
H	Wall Charger	1

NOTE

GreatLite and/or it's distributors have provided the parts list and assembly diagram as a reference only. Neither GreatLite and/or it's distributors make any representation or warranty of any kind to the buyer and/or user of this tool that he or she is qualified to do any repairs or replace any parts of this product. GreatLite and it's distributors expressly state that all repairs or parts replacement should be done by certified or licensed technicians. The buyer assumes all risk and liability arising out of his or her repairs or parts replacement to the original product.

Available to Order Separately:

- EXPE03 (1) 3.7 18650 Li-ion Battery
- EXPE02 Charging Unit with (1) 3.7V 18650 Li-ion Battery
- EXPE01 Charging Unit with (2) 3.7V 18650 L-ion Batteries

