

Model 99 Cable Gun Lock

HOW TO ATTACH AND LOCK

**WARNING: DO NOT USE THIS LOCK ON A LOADED GUN!
ATTEMPTS TO DO SO MAY RESULT IN AN ACCIDENTAL DISCHARGE! A LOADED GUN MUST
ALWAYS BE REGARDED AS DANGEROUS!**

The Master Lock gun cable lock works with a variety of firearms. It can be used to attach your firearms to stationary objects.

INSTALLATION:

1. Put safety in "on" position.
2. Unload all ammunition as explained in your firearm owner's manual.
3. Visually inspect chamber and magazine tube to ensure the firearm is completely unloaded.
4. Action must remain in the "open" position: **do not close the action.**
5. Unlock the gun lock cable using the key provided. Remove key.
6. Thread loose end of cable through the firearm's loading port and out the ejection port.
7. With the key still inserted in the lock press the unfastened end of the cable back into the hole in the lock body.
8. Pull on cable to make sure it is locked.

Note: Do not "work" action with cable in place. This can result in unnecessary abuse of the cable and firearm. Replace cable lock if protective coating separates from steel cable or if it fails to operate properly.

IMPORTANT: We do not guarantee that this product will lock all firearms. It will block access to many guns when properly attached. NO GUN LOCK CAN OFFER COMPLETE PROTECTION AGAINST THE ACCIDENTAL OR INTENTIONAL MISUSE OF FIREARMS. Keep guns unloaded and out of children's reach. Master Lock company is not responsible for incidental or consequential damages.

Looking for dependable gun maintenance? Rely on Master Lock for quality and long-lasting products.