

HOW TO COMPLETE YOUR MODULAR OUTDOOR KITCHEN COVER

1 Choose Your End Pieces

Qty 2 End Pieces - Depending on your kitchen, choose between:

- **Right & Left End** (1420-TN):
If your kitchen has 90° end
- **Round End Table - Right & Left** (1422-TN):
If your kitchen has a rounded end
- **BBQ Hood - Right & Left End** (1421-TN):
If your kitchen ends with a BBQ
- **Rounded End BBQ Hood - Right** (1425-TN):
If your kitchen ends with a rounded BBQ on the right
- **Rounded End BBQ Hood - Left** (1426-TN):
If your kitchen ends with a rounded BBQ on the left

2 Choose Your BBQ Piece

Qty 1 BBQ Piece - If your BBQ is not located at end:

- **BBQ Hood - In Line** (1423-TN)

3 Add Your Corner Piece(s)

Corner Piece - Qty depends on your kitchen configuration

- **Corner** (1424-TN)

4 Fill In With Extensions

Extension Pieces to fill in the rest of your cover:

- **12" Extension** (1427-TN)
- **24" Extension** (1428-TN)

QTY depends on your kitchen configuration



**PIECES USED FOR
CONFIGURATION SHOWN ABOVE:**

RLE

RIGHT & LEFT END
1420-TN

BHI

BBQ HOOD - IN LINE
1423-TN

24E

24" EXTENSION
1428-TN

12E

12" EXTENSION
1427-TN

COR

CORNER
1424-TN

**OUTDOOR KITCHEN
COVER**