

# **MEGAPHONE/BULLHORN**

Professional Megaphone with Siren & LED Lights



Model: PMP37LED



This user manual contains important information for safe operation and optimal megaphone performance. Please carefully read and follow safety notes and instructions. Save this manual for future reference. Make sure that it is available to all persons using this device.

## SAFETY

This megaphone is intended to be used only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or device damage. Please use the megaphone as described and under supervision if used by children or minors.

- Ensure that plastic bags, packaging, etc.
- Never let children unattended use electrical devices.
- Use proper polarity is observed when inserting batteries.
- Incorrectly inserted batteries may cause damage and risk of fire.
- Leaking batteries can cause permanent damage to the device.
- Remove batteries if the megaphone will not be used for long periods of time.

## **OPERATING INSTRUCTIONS**

Voice Mode:

- Slide the switch on the rear of the megaphone to voice
- · Adjust the desired volume level using the rear of the megaphone

Record Mode:

- Slide the switch on the rear of the megaphone to record
- Slide the button of play to emit recorded sounds.

LED Mode

· Slide the switch on the rear of the megaphone to use led light

#### **BATTERY INSERTION**

Press the button located near the back, underside of the megaphone. The button will release the lid to reveal the battery compartment.

Please see correct battery direction placement on the top side of the opening battery compartment lid. Insert batteries, close the cover and fasten clip until locked.

**NOTE:** Make sure the batteries are inserted correctly observing correct polarity.



#### **FEATURES & SPECIFICATIONS:**

- 800 Yard Range
- Power Output: 30 Watts
- For Indoor/Outdoor Use
- Adjustable Volume Control
- Used By U.S. Armed Forces
- Button Activated LED Light Mode
- Button Activated Siren Alarm Mode
- Lightweight, Portable & Powerful
- Battery Powered by 4 x 'D' Batteries, Not Included
  - Dimensions: Diameter 6.2" x Length 10.0" Discover other marine audio on our website.