




ROTHCO



How to Measure for Frame Sizing

1. Stand in front of a mirror.
2. Hold a ruler so one end is lined up with your right temple and so that ruler goes over the bridge of your nose.
3. Measure the distance between your temples to the nearest 1/4 inch. Accuracy to 1/8th inch is even better. Keep ruler straight. Do not bend.
4. Use the chart below to determine the frame size that would be the best fit and suit your face.

| | |
|-------------------------|----------------------------------|
| 52mm Frame | Up to 5 in (127mm) |
| 55mm Frame | 5 in to 5 1/2 in (128mm - 140mm) |
| 57 and 58mm Frame | 5 1/2in to 6 in (141mm - 152mm) |

* Temple Length is determined by frame size.