


Installation Instructions

Shade Logic Sun Shade Sail







COLOR	LENGTH	No.
Terracotta	12 ft. / 3,7 m	25670
Terracotta	16 ft. / 4,9 m	25671
Lime Green	12 ft. / 3,7 m	25674
Lime Green	16 ft. / 4,9 m	25675
Sand	12 ft. / 3,7 m	25720
Sand	16 ft. / 4,9 m	25721
Evergreen	12 ft. / 3,7 m	25724
Evergreen	16 ft. / 4,9 m	25725
Sea Blue	12 ft. / 3,7 m	25733
Sea Blue	16 ft. / 4,9 m	25734
△ TRIANGLE	Δ	

ATTENTION: Please read this installation manual completely. If you have any questions, please contact customer service at the number listed below.

CAUTION: Choose location carefully. Make sure attachment posts and structures are sturdy enough to withstand the pull of the product on windy days. Stay clear of electrical wires, utility lines, tree branches, open flame, and other structures. Do not hang objects from the sail or support cables. If inclement weather is forecasted, take down and store away Sun Shade Sail to prevent damage.

INSTALLATION: Proper installation is the responsibility of the consumer. **ShelterLogic® Corp.** is not responsible for damage to the unit or personal property that occur from acts of nature. A sail that is not installed securely has the potential to fly away causing damage and is not covered under warranty. Ensure mounting points are structurally sound and hardware is secured tightty. Continuously check and retighten connection points.

CARE / **CLEANING:** Keep the Sun Shade Sail taut. Loose fabric can accelerate deterioration. Sun Shade Sail is easily cleaned with mild soap and water, using a sponge or soft cloth. DO NOT machine wash. Avoid exposure to aggressive chemicals (e.g. chlorine) or hard-edged tools as it may damage the fabric.



