

# AMBIDEXTROUS SIDE-MOUNT QUIVER BRACKET INSTALLATION INSTRUCTIONS

1. The Ambidextrous Side-Mount Quiver Bracket Kit contains the following parts (photo 1):

Side-Mount Quiver Bracket (1)  
Phillips pan-head machine screws (2)

2. The standard TenPoint HX quiver package contains the following mounting parts (photo 2) (if the quiver & parts are currently installed on your crossbow, remove only the quiver, quick disconnect (female) attachment, and the two Phillips pan-head screws then skip to step 5):

- Quick disconnect (female) attachment with lever (1)
- Phillips pan-head machine screws (2)
- Quiver mounting bracket for TenPoint models (1)
- 7/16-inch Nylock Nuts & 3/4-inch setscrews (pre-assembled at the factory) (2)
- HX Instant Detach Quiver with quick disconnect (male) attachment (1)
- *Quiver mounting bracket for 6 Point models (1)*
- *5/8-inch socket-head cap screw (1)*
- *7/8-inch socket-head cap screw (1)*

3. If your quiver mount is not already installed, completely remove the two 1/4-inch setscrews holding the foot stirrup in place (n/a for models with an integrated foot stirrup) (photo 3).

4. Place the quiver's metal bracket assembly over the two holes you just removed the setscrews from.

The mounting bracket holes should face forward toward the foot stirrup (see photo 4 for orientation).

First, insert and tighten the two 3/4-inch setscrews (with Nylock nuts) into the same holes you removed the original setscrews from.

Then, tighten the two Nylock nuts until the quiver mounting bracket is secure. Use a 7/16-inch open-ended wrench to tighten.

**Note: Do no over-tighten.**

5. Choose which side you want the quiver located and attach the side-mount quiver bracket to the quiver mounting bracket assembly accordingly (the flanges on the side-mount bracket will be facing down from the bottom of the crossbow). Insert the two Phillips pan-head screws, through the bottom of the side-mount bracket, into the quiver mounting bracket assembly (photo 5).
6. Attach the female lever-lock attachment to the opposite end flange with two Phillips pan-head screws (photo 6).
7. Insert the HX Instant Detach Quiver with male attachment into the quick disconnect (female) attachment with lever, and lock into place (photo 7).

