



# Instructions

Thule Sleek Snack Tray  
11000302



### IMPORTANT

Keep these instructions for future reference. Your child's safety may be affected if you do not follow these instructions.

### WARNING!

- Ensure that all the locking devices are engaged before use.
- Do not let your child play with this product.
- The child carrier will become unstable if the manufacturer's recommended load is exceeded.
- Do not use the Thule Sleek Snack Tray to hold hot liquids or food items.
- Not designed to restrain the child.
- Avoid serious injury from falling or sliding out. Always use seat belt.
- Do not lift the stroller by the tray.
- Remove the tray before folding the stroller.
- Do not use in rough terrain.

### MAINTENANCE

The tray is dishwasher safe.

### IMPORTANT INFORMATION

Thule Sleek Snack Tray is compatible with Thule Sleek.

