



# > Instructions

Thule Sleek  
Mesh Cover Bassinet  
11000310



501-8373-02

Bring your life

### IMPORTANT

Keep these instructions for future reference. Your child's safety may be affected if you do not follow these instructions.

### ⚠ WARNING!


- Never leave your child unattended.
- Do not use this child carrier around or near an open fire or exposed flame. Carelessness causes fire.
- Do not let your child play with this product.

### MAINTENANCE


- Thule Sleek Mesh Cover Bassinet can be gently machine wash separately or with like items using mild soap & warm water.
- Maximum water temperature 30 degrees Celsius.
- Rinse well & spin dry with no heat. Hang to air dry completely.
- No bleach. Do not iron. Do not dry clean.

### IMPORTANT INFORMATION



Thule Sleek Mesh Cover Bassinet is compatible with Thule Sleek Bassinet.





1



i



2



i

