Instructions RC126

This is a resetable combination lock so that you can reset the combination as often as you like.

Operating Instructions:

This lock is preset to operate at 0000. To set your own combination, follow the steps below:

- 1.Dial the combination wheels to 0000 and withdraw the cable.
- 2. Turn the knob 90 degrees clockwise to the designated position.
- Reset the combination wheels to the desired combination, making sure the numbers are lined up with the pointer.
- Have selecting your combination numbers, turn the knob back to the original position in a counterclockwise direction.
- The new combination is now set.
- 6. Repeat the 1-5 steps above to reset the combination anytime you like.

