

SHOOTER

**PULL THE TRIGGER TO OPEN JAWS,
LET UP TO CLOSE!**

THE **SHOOTER** SERIES FEATURES FOUR BRIGHT COLOR COMBINATIONS OF RED WHITE AND BLUE, GREEN AND BLACK, RED AND GOLD, AND PURPLE AND BLACK. PULL TRIGGER TO OPEN FULLY-INDEPENDENT STANDARD CALIPER JAWS, AND LET UP THE TRIGGER TO CLOSE. THE **SHOOTER** HAS A QUICK LOCK CONNECTION SYSTEM TO PROVIDE EASY ADJUSTMENT FOR ANY ANCHOR POINT. THE ROPE STYLE CONNECTION BETWEEN THE HEAD AND STRAP ALLOWS FOR LESS TORQUE AND GREATER ACCURACY, WHILE ALSO ALLOWING THE LENGTH OF THE RELEASE TO BE EXTREMELY SHORT TO FIT SMALLER HANDS. TUCKS AWAY EASY INTO SLEEVE WHEN NOT IN USE. AVAILABLE IN JUNIOR OR LARGE WITH CHOICE OF BLACK VELCRO® STRAP OR BLACK LEATHER BUCKLE STRAP.



QUICK LOCK CONNECTION SYSTEM

SENSITIVITY ADJUSTMENT SCREW



CALIPER SENSITIVITY ADJUSTMENT

(See Sample A) Hold bow string in one hand and pull release away from you with the other hand when making release sensitivity adjustments. **Never draw bow while setting sensitivity.** To achieve the

Sample A



lightest setting, turn the sensitivity adjustment screw in 1/4 turn increments until it fires prematurely. At this point, back the set screw out 1/16 turn until the release fires prematurely at a pull of around 50 lbs. or greater. Then, back the screw out 1/4 turn (1/2 turn for Assassin Models) and your release will be at its lightest suggested setting. Back the screw out 1/8 turn at a time for a stiffer trigger. Use blue Loc-Tite (#242) if screw is adjusted more than once! Not for use with thinly braided rope loops or rope material under 2mm dia. Call us for quality rope loop made for these release aids!

WARNING:

ALWAYS INSURE RELEASE IS ADJUSTED TO A SAFE SETTING BEFORE DRAWING BOW! NEVER DRAW BOW WITHOUT AN ARROW! NEVER POINT YOUR BOW IN AN UNSAFE DIRECTION!

THINK AND ACT SAFELY!

WARNING:

- * NEVER DRAW BOW WITHOUT AN ARROW!
- * ALWAYS POINT BOW AT A SAFE TARGET! NEVER POINT BOW IN AN UNSAFE DIRECTION!
- * DO NOT LET GO OF THIS RELEASE DURING THE SHOT PROCESS!
- * ALWAYS KEEP ALL FINGERS BEHIND TRIGGER, WHEN DRAWING BOW, UNTIL READY TO FIRE!
- * NEVER PULL THE RELEASE TOWARD FACE WHEN DRAWING BOW!
- * INSPECT EQUIPMENT BEFORE USE TO INSURE PROPER OPERATING CONDITION!
- * FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN EQUIPMENT DAMAGE OR INJURY!
- * THINK AND ACT SAFELY!