


# SHORT-N-SWEET'R

THE EVER-POPULAR SHORT-N-SWEET GOT SHORT-N-SWEET'R! THE SHORT-N-SWEET'R'S LIGHTER AND SMALLER, TUBULAR-SHAPED BODY ALLOWS LESS OBSTRUCTION IN YOUR HAND AND MAKES IT EASY TO TUCK INTO YOUR SLEEVE WHILE NOT IN USE. THIS SHORT-N-SWEET'R RELEASE CONTAINS THE SAME FEATHER-LIGHT, NON-COLLAPSING TRIGGER THAT WAS POPULAR WITH THE SHORT-N-SWEET AND A SINGLE TRAVEL SCREW FOR ADJUSTING THE FEEL OF TRIGGER PRESSURE TO CUSTOMIZED, INDIVIDUAL PREFERENCES. THE QUICK-LOADING, OPEN-HOOK DESIGN ALLOWS THE HUNTER A SPEEDY AND SECURE CONNECTION TO THE STRING LOOP WITHOUT NEEDING TO TAKE EYES OFF OF THE PRIZED GAME. THE SHORT-N-SWEET'R WILL ALSO COME STANDARD WITH THE CINCH STRAP: A MICRO-ADJUSTABLE WEB STRAP THAT CONTAINS A SINGLE SOCKET HEAD CAP SCREW THAT IS LOOSENED TO MAKE AN ADJUSTMENT FOR INFINITE DRAW LENGTH SETTINGS, AND THEN TIGHTENED TO LOCK THE WEBBING IN THE DESIRED POSITION. THE SHORT-N-SWEET'R IS AVAILABLE WITH A BLACK ANODIZED HEAD AND YOUR CHOICE OF THE VELCRO® OR BUCKLE CINCH STRAP IN JUNIOR, LARGE, OR X-LARGE SIZES. "KEEP YOUR EYE ON THE PRIZE"



## SHORT-N-SWEET'R SENSITIVITY ADJUSTMENT

Sample A

While pushing on the Short-N-Sweet'R jaw with finger, (See Sample A), turn the sensitivity screw clockwise slowly until the jaw opens. At this point, back the screw out counter-clockwise 1/4 turn and your release will be at its lightest setting.



Back the screw out 1/8 turn at a time for a stiffer trigger. Screw adjusted too far in a clockwise direction will cause release to fire prematurely. Insure sensitivity screw has resistance from lock screw to keep sensitivity screw from loosening. **Never draw bow while setting sensitivity.** The Short-N-Sweet'R release works with any rope loop!

### WARNING:

ALWAYS INSURE RELEASE IS ADJUSTED TO A SAFE SETTING BEFORE DRAWING BOW!  
NEVER DRAW BOW WITHOUT AN ARROW!  
NEVER POINT YOUR BOW IN AN UNSAFE DIRECTION!  
THINK AND ACT SAFELY!

## WARNING:

- \* NEVER DRAW BOW WITHOUT AN ARROW!
- \* ALWAYS POINT BOW AT A SAFE TARGET! NEVER POINT BOW IN AN UNSAFE DIRECTION!
- \* DO NOT LET GO OF THIS RELEASE DURING THE SHOT PROCESS!
- \* ALWAYS KEEP ALL FINGERS BEHIND TRIGGER, WHEN DRAWING BOW, UNTIL READY TO FIRE!
- \* NEVER PULL THE RELEASE TOWARD FACE WHEN DRAWING BOW!
- \* INSPECT EQUIPMENT BEFORE USE TO INSURE PROPER OPERATING CONDITION!
- \* FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN EQUIPMENT DAMAGE OR INJURY!
- \* THINK AND ACT SAFELY!