



Module No. 1536/1636/1817

GENERAL GUIDE

- Press **(B)** to change from mode to mode.
- After you perform an operation in any mode, pressing **(B)** returns to the Timekeeping Mode.

Operation of Module 1817 is identical to that of Modules 1536/1636. The only difference between these modules are the Module 1817 indicators, which are shown below. All illustrations in this User's Guide shows Modules 1536/1636 only.



TIMEKEEPING MODE

Day of the week
Date
PM indicator
Hour
Minutes
Seconds

- In the Timekeeping Mode, press **(C)** to switch between the 12-hour and 24-hour formats.
- Day of the week is displayed as follows.
SU: Sunday MO: Monday TU: Tuesday
WE: Wednesday TH: Thursday FR: Friday
SA: Saturday

About the backlight

- Holding down **(A)** at any time illuminates the display.
- The backlight of this watch employs an electroluminescent (EL) light, which loses its illuminating power after very long term use.
- Frequent use of the backlight shortens the battery life.

ALARM MODE

Hourly time signal on indicator
Alarm on indicator
Mode indicator
Hour
Minutes

When the Daily Alarm is switched on, the alarm sounds for 20 seconds at the preset time each day. When the Hourly Time Signal is switched on, the watch beeps every hour on the hour.

To set the alarm time

1. Hold down **(A)** while in the Alarm Mode until the hour digits start to flash on the display. The hour digits flash because they are selected.
2. Press **(A)** to change the selection in the following sequence.

```


    Hour → Minutes → Normal Alarm Mode (No digit flashes) → Hour
    
```

- Once you reach the normal Alarm Mode, you have to hold down **(A)** again until the hour digits start to flash.
- 3. Press **(C)** to increase the selected digits. Holding down **(C)** changes the number at high speed.
- The format (12-hour and 24-hour) of the alarm time matches the format you select for normal timekeeping.
- When setting the alarm time using the 12-hour format, take care to set the time correctly as morning or afternoon (PM).
- 4. After you set the alarm time, press **(A)** to return to the Alarm Mode. At this time the Daily Alarm is switched on automatically.

To stop the alarm

Press **(A)** to stop the alarm after it starts to sound.

To switch the Daily Alarm and Hourly Time Signal on and off
Press **(C)** while in the Alarm Mode to change the status of the Daily Alarm and Hourly Time Signal in the following sequence.



To test the alarm

Hold down **(C)** while in the Alarm Mode to sound the alarm.

STOPWATCH MODE

Split time indicator
Mode Indicator
Minutes
1/100 second
Seconds

The Stopwatch Mode lets you measure elapsed time, split times, and two finishes. The range of the stopwatch is 59 minutes, 59.99 seconds.

(a) Elapsed time measurement



(b) Split time measurement



(c) Split time and 1st-2nd place times



TIME SETTING MODE

Day of the week
PM indicator
Date
Hour
Minutes
Seconds

To set the time and date

1. Use **(B)** to enter the Time Setting Mode.
 - The seconds digits flash because they are selected.
2. Press **(A)** to change the selection in the following sequence.


```

                Seconds → Hour → Minutes → Day of Week ← Date ← Month
            
```
3. While the seconds digits are selected (flashing), press **(C)** to reset the seconds to "00". If you press **(C)** while the seconds count is in the range of 30 to 59, the seconds are reset to "00" and 1 is added to the minutes. If the seconds count is in the range of 00 to 29, the minutes count is unchanged.
4. While any other digits (besides seconds) are selected (flashing), press **(C)** to increase the number. While the day of the week is selected, pressing **(C)** advances to the next day. Holding down **(C)** changes the current selection at high speed.
5. After you set the time and date, press **(B)** to return to the Timekeeping Mode.

- If you do not operate any button for a few minutes while a selection is flashing, the flashing stops and the watch goes back to the Timekeeping Mode automatically.