



SPORTSMAN'S GRILL ASSEMBLY

1. Attach the **Fire Bowl** to the **Footed Base** with the nuts and bolts provided. Do not overtighten.
2. Slide the **Wire Bail** through the holes on either side of the **Fire Bowl**.
3. Set the **Fire Door** in the 2 loop holders on the front of the **Fire Bowl**. The door swings open to load charcoal or remove ashes.
4. Slide the **Draft Door** in the grooved area on the front of the **Footed Base**. Slide it left or right to adjust air flow.


Cooking: Place charcoal on top of the **Fire Grate** and ignite. The grill should always be placed on bricks or other fire retardant material.



Cooking Grate // Item# 3051



Fire Grate // Item# 3050




Wire Bail

Fire Bowl // Item# 3059

Footed Base // Item# 3055



Draft Door // Item# 3056



Fire Door // Item# 3058

The following use and care instructions for Lodge Seasoned Cast Iron will help your cookware last a lifetime.

If you do Nothing Else...

Hand wash. Dry immediately—even before first use.

Rub with a light coat of vegetable oil after every wash.

How much oil? Enough to restore the sheen, without being "sticky".

Why? To keep the iron "seasoned" and protected from moisture.

Seasoning—It isn't Salt and Pepper

"Seasoning" is vegetable oil baked onto the iron at a high temperature: not a chemical non-stick coating.

Seasoning creates the natural, easy-release properties. The more you cook, the better it gets.

Because you create, maintain, and even repair the "seasoning", your cookware can last 100 years or more. Chemical non-stick coating cannot be repaired, limiting lifespan.

Let's Cook!

Lodge Cast Iron is right at home on induction, ceramic, electric and gas cooktops, in your oven, on the grill, or even over the campfire. Do not use in the microwave. (Some induction tops will not work with 2-burner griddles)

On glass or ceramic cooktops, lift cookware; never slide it.

Our cookware is safe at high temperatures; use metal, wood, or hi-temp silicone utensils.

Some foods may stick to new cookware (especially eggs). Use a little extra oil or butter until you've built up the seasoning.

Acidic foods like tomatoes, beans, and certain sauces can damage seasoning, and should be avoided until the seasoning is well-established.

Cast Iron rarely needs to go above a medium heat setting when properly pre-heated. For the times when you do cook at higher temperatures, bring the pan to temperature gradually and add oil to just before adding food to prevent sticking.

Our handles get hot; use mitts. Use trivets to protect countertops from hot cookware.

To Soap or not to Soap...

If no soap is too scary, wash with mild soapy water and dry and oil immediately. However, consider that cookware is 400°F in 4 minutes on medium heat and is sterile at 212° F, so soap isn't always necessary.

Dishwashers, strong detergents and metal scouring pads are not recommended, as they remove seasoning.

Rust?! Don't Panic, it's not Broken

Without protective seasoning iron can rust.

It's really easy to fix. Scour the rust, rinse, dry, and rub with a little vegetable oil.

If problem persists, you will need to thoroughly remove all rust and follow our re-seasoning instructions (below).

Refurbish Your Finish

While maintaining the seasoning should keep your Cast Iron and Carbon Steel in good condition, at some point you may need to re-season your cookware. If food sticks to the surface, or you notice a dull, gray color, repeat the seasoning process:

- * Wash the cookware with hot, soapy water and a stiff brush. (It is okay to use soap this time because you are preparing to re-season the cookware).
- * Rinse and dry completely.
- * Apply a very thin, even coating of MELTED solid vegetable shortening (or cooking oil of your choice) to the cookware inside and out. Too much oil will result in a sticky finish.
- * Place aluminum foil on the bottom rack of the oven (not directly on bottom) to catch any drips.
- * Set oven temperature to 350 – 400 degrees F.
- * Place cookware upside down on the top rack of the oven to prevent pooling.
- * Bake the cookware for at least one hour. After the hour, turn the oven off and let the cookware cool in the oven.
- * Store the cookware uncovered, in a dry place when cooled.
- * Repeat as necessary.

Some Basics

Gas flames should not extend up the sides of cookware.

Match pan size to burner size.

Don't use in the microwave.

When deep frying, fill cookware only to 1/3 of capacity.