




Spark<sup>™</sup>, Spark<sup>™</sup> 2.0 & Spark<sup>™</sup> Ultra























### Fold scooter.

1










### Replace spark cartridge.






Hot after use! Allow to cool.





### Align front wheel and handlebars.






## Clamp tensioner too loose.










### Clamp tensioner too tight.









# Lower handlebars from maximum height.










## Spark 2.0











#### WARNING. To avoid serious injury:

- · Adult supervision always recommended.
- · This product is sport/transport equipment.
- Parents and carers should ensure that children are properly instructed in the use of this product.
- Hold handlebars at all times.
- Ride outdoors in places that allow you to improve your skills, and NEVER in traffic, on roads or near motor vehicles, where serious accidents can happen. Watch your surroundings for pedestrians, and bike, skateboard, scooter and other riders. Use in areas free from hazards such as poles, hydrants, and parked cars.
- Wet weather impairs traction, braking and visibility.
- Never use near streets, swimming pools, hills, or steps. Use on smooth, dry, paved surfaces; avoid excessive speed associated with downhill rides. Don't ride on loose debris (such as rocks, gravel or sand), or speed humps. Do not ride in the dark.
- Always wear shoes when using this product.
- Allow only one rider at a time on this product.
- Like any other moving product, riding this product can be a dangerous activity and may result in injury even when used with proper safety precautions.
- Do not touch the brake or spark cartridge after using. They will be hot



#### WARNING. Sparks Can Induce Fire.

### To reduce risk of serious injury or fire:

- · Adult supervision always recommended.
- Parents and carers should make sure riders understand that sparks can start a fire.
- Keep sparks away from flammable or combustible substances.
- Use only outdoors and on solid, clean, dry, hardened surfaces.
- Keep away from substances that can catch fire such as dry
- Do not use in areas prone to wildfires or posted by fire authorities as area at risk for fires.
- Never use scooter to try to start a fire.

vegetation, paper, chemicals or gasoline.

- The skill required to ride this product may be greater than that required to ride a traditional kick scooter.
- Applying too much pressure to the Spark Bar may cause loss of control.
- Do not depress Spark Bar continuously only for short periods – while the scooter is moving, as this may overheat components. Always allow to cool (at least 15 minutes recommended) before replacing a worn spark cartridge.
- · Do not ride at night.
- · Keep sparks away from eyes, hair, skin and clothing.
- · Spark Bar and brake get hot during use. Do not touch after use.

#### **Age and Weight Limits**

- · Not for children under age 8.
- · Maximum rider weight 100 kg (220 lbs).

#### **Protective Equipment**

 Always wear protective equipment - helmet, elbow, knee and wrist guards (note parents should evaluate whether their child's use of wrist guards may impair their ability to hold handlebars).

Failure to use common sense and heed the above warnings further increases risk of serious injury. Use at your own risk and with appropriate and serious attention to safety. Use caution.

#### Where and How to Ride

- · Stop by pushing on brake with foot.
- Create sparks by placing ball of foot on spark bar and apply pressure gradually, only using enough pressure to cause sparking action.
- · Learn to fall (by rolling if possible) without the product.
- · Learn with a friend or parent to help.
- This product was manufactured for performance and durability. Trick riding can, over time, stress or damage any product.
- Risk of injury increases as degree of trick difficulty and product stress increases
- Rider assumes all risks associated with trick riding.
- You may see people in videos, or people you know, doing tricks. These people have been practicing for a long time and accept the risks of trick riding. Do not assume you can try tricks without great risk.
- Check local laws regarding where and how you may use your product.

#### Maintenance

- Always inspect product before riding and regularly maintain it. If any parts are loose or broken, do not use. Replace worn or damaged parts such as grips, handlebars, handlebar endcaps or worn wheels
- Check that the steering system is correctly adjusted and that all connection components are firmly secured and not broken.
- Check brake for proper function. When you push on the brake with your foot, brake should provide positive braking action.
- Under normal circumstances and conditions, the wheels and bearings are maintenance free.
- Regularly check that the various screwed parts are tight.
- · No modifications can be made that can impair safety.
- Wipe with a damp cloth to remove dirt. Do not use alcohol, alcohol-based or ammonia-based cleaners as they may damage the plastic components.
- Use only authorized Razor replacement wheels and spark cartridges.



#### WARNING. Battery (Spark 2.0)

- Lithium batteries included for lights adult attention for changing and disposal.
- Battery should only be replaced by an adult.
- Loose battery could present a choking hazard and should be kept away from small children.
- Dispose of batteries properly.