



CARE AND USE GUIDE

FUNTAINER WATER BOTTLE AND FOOD JAR (F410, F411, F310)

GENERAL CARE


- Before first use, and as soon as possible after each use, wash all parts with warm, soapy water. Rinse all parts thoroughly and allow time to dry.
- Contents should not be left in the container for longer than 24 hours. As soon as possible after each and every use, wash all parts with warm, soapy water. Rinse all parts thoroughly with clean water. Allow all parts to dry completely prior to next use or storage.
- DO NOT use abrasive cleaners or scrubbers since they may dull the finish.
- DO NOT use bleach or cleaners containing chlorine on any parts of the product.
- This product is top-rack dishwasher safe; however, washing by hand is recommended as the dishwasher uses harsher detergents and hot water that may affect the appearance of your product.
- Residual contents may become trapped between parts, under gaskets (flexible band around lid and/or stopper), or in straws. Although this products is top-rack dishwasher safe, washing by hand is recommended to ensure that these parts of the product are thoroughly cleaned.
- For maximum thermal insulation efficiency, preheat (Food Jar only) or pre-chill (Food Jar and Bottles) the product just prior to use. Fill with hot/cold tap water, attach lid, let stand 5 to 10 minutes and empty. After filling container with contents, re-cover with lid to increase thermal efficiency. Never use a microwave, conventional oven, or other heat source for this purpose.

ASSEMBLY & USE

Food Jar:

1. Remove lid (A) by twisting counterclockwise.
2. Remove spoon (D) (if present) by pulling up on it.
3. Remove o-ring gasket (B) from underside of lid (A).
4. Wash all parts separately, then re-assemble o-ring gasket (B) with flat side facing lid (A).
 - a. Ensure gasket (B) is properly seated to minimize leaking.
5. Fill container with contents. Do not overfill: Leave space for the lid (A), to avoid overflow.
6. Replace lid (A) by twisting clockwise.


See WARNINGS Section below for further details.



* Image for reference only: actual product may vary

Push-Button Spout Bottle:

1. Remove lid (D) by twisting counterclockwise.
2. Press the push-button (D1) on the lid (D) to open lid cover (E).
3. Pull out spout gasket (E1) from underside of lid cover (E) to completely remove it.
4. Remove o-ring gasket (F) from underside of lid (D).



* Image for reference only: actual product may vary


5. Wash all parts separately and re-assemble.
 - a. Ensure gaskets (E1 and F) are properly seated to minimize leaking.
6. Fill container with contents. Do not overfill: Leave space for the lid (D), to avoid overflow.
7. Replace lid (D) by twisting clockwise.
8. To drink, press the push-button (D1) located on the lid (D) to release the lid cover (E) and reveal the drink opening.
9. When finished drinking, close the lid cover (E) until it snaps securely into place.

See WARNINGS Section below for further details.

Push-Button Straw Bottle:

1. Remove lid (G) by twisting counterclockwise.
2. Press the push-button (G1) on the lid (G) to open lid cover (G2).
3. Using your thumbs, push sipper straw (H) downward through lid (G).
4. Pull the straw stem (I) out of bottom of sipper straw (H).
5. Wash all parts separately and re-assemble.
6. Fill container with contents. Do not overfill: Leave space for the lid (G) and straw stem (I), to avoid overflow.
7. Replace lid (G) by twisting clockwise.
8. To drink, press the push-button (G1) located on the lid (G) to release the lid cover (G2) and reveal the drink opening.
9. When finished drinking, close the lid cover (G2) until it snaps securely into place.

Note: A worn sipper straw (H) may cause the product to leak. Check sipper straw (H) regularly and replace immediately if damaged or worn



* Image for reference only: actual product may vary

WARNINGS (FOOD JAR ONLY):

- Use only with adult supervision, especially when product contains hot contents — hot liquids or hot foods can burn or scald user.
- DO NOT overfill product. Leave space at top of container for lid and stopper (if present), to avoid overflow. Overflow of hot foods or liquids can burn or scald user.
- Always test temperature of food or liquid before feeding to your child.
- To avoid possible injury, do not let child walk or run with product.
- Check the gasket periodically. Leakage of hot contents may burn or scald user.

WARNINGS (BEVERAGE BOTTLES ONLY):

- NOT FOR USE WITH HOT LIQUIDS: For cold liquids only. Hot liquids may cause burns or scald user.
- Use only with adult supervision. To avoid possible injury, do not let child walk or run with product.
- To avoid possible injury, do not let child chew on the soft material of the straw (if present) as it may present a choking hazard.
- Check straw (if present) regularly for tears and replace immediately if damaged or worn.
- Continuous and prolonged sucking of fluids such as fruit juices or flavored sugary drinks may cause tooth decay.
- DO NOT overfill product. Leave space at top of bottle for lid and straw (if present) to avoid overflow.

WARNINGS (BOTH FOOD JAR AND BEVERAGE BOTTLES):

- DO NOT use product in microwave, on stove top, or in any type of oven.
- Never leave child unattended while using this product.
- Always test temperature of food or liquid before consuming and before feeding to your child.
- DO NOT overfill the container: Leave space at top of container for lid, straw (if present) and stopper (if present), to avoid overflow.
- Check periodically to make sure any gasket (flexible band around lid and/or stopper) is present and properly positioned to prevent contents from passing through lid when lid is closed. Missing, worn or misaligned gaskets may cause product to leak.
- In general, contents should not be left in container for longer than 24 hours. However, the rate at which contents spoil depends on several factors. Certain contents that include, for example, dairy, homemade soup, and/or tomato may start to spoil much sooner. Also, spoilage may occur faster when contents have been partially consumed. In addition, spoilage may occur sooner with the opening and reclosing of a product holding contents. Proceed with caution when using the product with quick spoiling or partially consumed contents, as pressure may build up in the container and possibly cause forceful ejection of the stopper or contents.
- If contents are left in container longer than 24 hours, or you suspect spoilage, use caution when opening container. Contents spoilage can cause pressure inside container to build, possibly leading to forceful ejection of stopper or contents. In such circumstances, before attempting to open container,

ENSURE THE OPENING IS POINTED AWAY FROM THE USER OR OTHER PERSONS TO AVOID INJURY.

- DO NOT use tools or devices to force container to open.
- If you are unable to open container by hand, do not open it and dispose of it at your local waste facility.
- DO NOT use to store or carry carbonated drinks or dry ice. This may cause lid/stopper and contents to eject forcefully or leak.