

# WEIDER®Flat Bench

### Model No. WEBE39317.0 Serial No.

Write the serial number in the space above for reference.



### **USER'S MANUAL**



### **ACAUTION**


Read all precautions and instructions in this manual before using this equipment. Keep this manual for future reference.



### **TABLE OF CONTENTS**

WARNING DECAL PLACEMENT	2
MPORTANT PRECAUTIONS	3
BEFORE YOU BEGIN	
ASSEMBLY	6
EXERCISE GUIDELINES	8
PART LIST/EXPLODED DRAWING	1 .

### WARNING DECAL PLACEMENT



### IMPORTANT PRECAUTIONS

WARNING: To reduce the risk of serious injury, read all important precautions and instructions in this manual and all warnings on your weight bench before using your weight bench. ICON assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

- It is the responsibility of the owner to ensure that all users of the weight bench are adequately informed of all precautions
- Before beginning any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.
- The weight bench is not intended for use by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge, unless they are given supervision or instruction about use of the weight bench by someone responsible for their safety.
- 4. Use the weight bench only as described in this manual.
- 5. The weight bench is intended for home use only. Do not use the weight bench in any commercial, rental, or institutional setting.
- Keep the weight bench indoors, away from moisture and dust. Do not put the weight bench in a garage or covered patio, or near water.
- Place the weight bench on a level surface, with enough clearance around the weight

- bench to mount, dismount, and use the weight bench. To protect the floor or carpet from damage, place a mat under the weight bench.
- 8. Inspect and properly tighten all parts each time the weight bench is used. Replace any worn parts immediately.
- 9. Keep children under age 13 and pets away from the weight bench at all times.
- 10. Wear appropriate clothes while exercising; do not wear loose clothes that could become caught on the weight bench. Always wear athletic shoes for foot protection while using the weight bench.
- 11. The weight bench is designed to support a maximum user weight of 350 lbs. (159 kg), and a maximum total weight of 460 lbs. (209 kg). Do not use the weight bench with more than 110 lbs. (50 kg) of weight, including a barbell. Note: The weight bench does not include weights or a barbell.
- 12. Over exercising may result in serious injury or death. If you feel faint, if you become short of breath, or if you experience pain while exercising, stop immediately and cool down.

## **PROTECT**

# YOUR FITNESS EQUIPMENT WITH AN EXTENDED SERVICE PLAN

Your new fitness equipment is not an ordinary purchase; it is an investment in your health and well being for years to come.

As the leading provider of manufacturer's extended service plans, ICON strives to protect your equipment and your future.

Please review the following service plans and find one that best fits your needs.



#### PREVENTIVE MAINTENANCE SERVICE PLANS

Equipment Price	3-Year Plan	5-Year Plan
\$0.00 to \$1000.00	\$199.99	\$289.99
\$1001.00 to \$1500.00	\$259.99	\$379.99
\$1501.00 to \$2500.00	\$339.99	\$489.99
(Bikes/Systems Only) \$0.00 to \$2500.00	\$139.99	NA

#### Features:

- Includes an annual preventive maintenance and performance check at your convenience
- Unlimited in-home repairs; no shipping required
- Covers parts and labor on all manufacturer's defects, as well as wear and tear on parts
- Up to 5 years of coverage available

#### STANDARD SERVICE PLANS

Equipment Price	1-Year Plan	2-Year Plan	3-Year Plan
\$0.00 to \$300.00	\$29.99	\$39.99	\$59.99
\$301.00 to \$1000.00	\$89.99	\$119.99	\$149.99
\$1001.00 to \$2000.00	\$109.99	\$139.99	\$179.99
\$2001.00 to \$3000.00	\$179.99	\$209.99	\$239.99

#### Features:

- Unlimited in-home repairs; no shipping required
- Covers parts and labor on all manufacturer's defects, as well as wear and tear on parts
- Up to 3 years of coverage available

To protect your fitness equipment today, please call Customer Care at 1-800-677-3838.


Or, visit us online at WWW.utserv.com.



### **BEFORE YOU BEGIN**

Thank you for selecting the WEIDER® FLAT BENCH weight bench. The FLAT BENCH weight bench is designed to help you develop the major muscle groups of your upper body. Whether your goal is to tone your body, build dramatic muscle size and strength, or improve your cardiovascular system, the weight bench will help you to achieve the specific results you want.

For your benefit, read this manual carefully before you use the weight bench. If you have questions after reading this manual, please see the front cover of this manual. To help us assist you, note the product model number and serial number before contacting us. The model number and the location of the serial number decal are shown on the front cover of this manual.



### **ASSEMBLY**

- Assembly requires two persons.
- Place all parts in a cleared area and remove the packing materials. Do not dispose of the packing materials until you finish all assembly steps.
- In addition to the included tool(s), assembly requires the following tools:


an adjustable wrench



Assembly may be easier if you have a set of wrenches. To avoid damaging parts, do not use power tools.

- 1. Go to meiderfitness on your computer and register your product.
  - · documents your ownership
  - activates your warranty
  - ensures priority customer support if assistance is ever needed


Note: If you do not have internet access, call Customer Care (see the front cover of this manual) and register your product.




2. Orient a Base (2) so that the widest sides of the Base Caps (4) touch the floor.

Attach the Base (2) to the Frame (1) with two M10 x 65mm Carriage Bolts (6) and two M10 Locknuts (8).

Attach the other Base (2) in the same way.



3. Attach the Bench (3) to the Frame (1) with three M8 x 55mm Screws (7) and three M8 Washers (9); start all the Screws, and then tighten them. To avoid damaging the Bench, tighten the Screws only until the Bench does not move or feel loose.



4. **Make sure that all parts of the weight bench are properly tightened.** Extra parts may be included. Place a mat under the weight bench to protect the floor.

### **EXERCISE GUIDELINES**

#### FOUR TYPES OF STRENGTH WORKOUTS

Note: A "repetition" is one complete cycle of an exercise, such as one sit-up. A "set" is a series of repetitions.

**Muscle Building**—Work your muscles near their maximum capacity and progressively increase the intensity of your exercise. Adjust the intensity level of an individual exercise as follows:

- · Change the amount of resistance used.
- Change the number of repetitions or sets performed.

Use your own judgment to determine the amount of resistance that is right for you. Begin with 3 sets of 8 repetitions for each exercise you perform. Rest for 3 minutes after each set. When you can complete 3 sets of 12 repetitions without difficulty, increase the amount of resistance.

**Toning**—Tone your muscles by working them to a moderate percentage of their capacity. Select a moderate amount of resistance and increase the number of repetitions in each set. Complete as many sets of 15 to 20 repetitions as possible without discomfort. Rest for 1 minute after each set. Work your muscles by completing more sets rather than by using high amounts of resistance.

**Weight Loss**—To lose weight, use a low amount of resistance and increase the number of repetitions in each set. Exercise for 20 to 30 minutes, resting for a maximum of 30 seconds between sets.

**Cross Training**—Combine strength training and aerobic exercise by following this type of program:

- Strength training workouts on Monday, Wednesday, and Friday.
- 20 to 30 minutes of aerobic exercise on Tuesday and Thursday.
- One full day of rest each week to give your body time to regenerate.

#### **WORKOUT GUIDELINES**

Familiarize yourself with the equipment and learn the proper form for each exercise. Use your own judgment

to determine the appropriate length of time for each workout, and the numbers of repetitions and sets to complete. Progress at your own pace and be sensitive to your body's signals. Follow each workout with at least one day of rest.

**Warming Up**—Start with 5 to 10 minutes of stretching and light exercise. A warm-up increases your body temperature, heart rate, and circulation in preparation for exercise.

**Working Out**—Include 6 to 10 different exercises in each workout. Select exercises for every major muscle group, emphasizing areas that you want to develop. To give balance and variety to your workouts, vary the exercises from workout to workout.

**Cooling Down**—Finish with 5 to 10 minutes of stretching. Stretching increases the flexibility of your muscles and helps to prevent post-exercise problems.

#### **EXERCISE FORM**

Move through the full range of motion for each exercise and move only the appropriate parts of the body. Perform the repetitions in each set smoothly and without pausing. The exertion stage of each repetition should last about half as long as the return stage. Exhale during the exertion stage of each repetition and inhale during the return stroke. Never hold your breath.

Rest for a short period of time after each set:

- Muscle Building—Rest for three minutes after each set.
- Toning—Rest for one minute after each set.
- Weight Loss—Rest for 30 seconds after each set.

#### STAYING MOTIVATED

For motivation, keep a record of each workout. Write the date, the exercises performed, the resistance used, and the numbers of sets and repetitions completed. Record your weight and key body measurements once a month. To achieve good results, make exercise a regular and enjoyable part of your life.

#### **EXERCISE LOG**

Make copies of this page, and use the copies to schedule and record your strength and aerobic workouts. Scheduling and recording your workouts will help you to make exercise a regular and enjoyable part of your life.

· ·										
<b>Strength</b> Date:	Exercise	Lbs.	Sets	Reps	Exercise			Lbs.	Sets	Reps
	1.				6.					
	2.				7.					
	3.				8.					
	4.				9.					
	5.				10.					
Aerobic Date:	Exercise				Time Dist				ance Speed	
Strength			ı	1				<u> </u>	ı	İ
Date:	Exercise	Lbs.	Sets	Reps	Exercise			Lbs.	Sets	Reps
/_/_	1.				6.					
	2.				7.					
	3.				8.					
	4.				9.					
	5.				10.					
Aerobic	[						<u> </u>		Ι .	
Date:	Exercise				Time Dis			ance Speed		
Strength	Exercise	Lbs.	Sets	Reps	Exercise			Lbs.	Sets	Reps
Date: / /	1.		00.0	Торо	6.				0010	rtopo
	2.									
	3.				7.					
	4.				9.					
	5.				10.					
Aerobic Date:	Exercise					Time	Dista	ance	Sp	eed
/_/									i –	

### PART LIST/EXPLODED DRAWING

Model No. WEBE39317.0 R1217A

Key No.	Qty.	Description	Key No.	Qty.	Description
1	1	Frame	6	4	M10 x 65mm Carriage Bolt
2	2	Base	7	3	M8 x 55mm Screw
3	1	Bench	8	4	M10 Locknut
4	4	Base Cap	9	3	M8 Washer
5	2	Frame Cap	*	_	User's Manual

Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual. \*These parts are not illustrated.

