

Econ Kit Instruction (AH-AADK)

Battery Installation

1. Remove varmint guard by carefully unsnap 3 lock tabs from the unit.
2. Remove battery cover by unsnap the lock tab.
3. Install 4 x AA size battery. Make sure batteries are installed in the correct polarity.



- Do not mix old and new batteries.
- Do not mix alkaline, standard, or rechargeable batteries.

PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO SET THE CLOCK

SETTING THE CLOCK TIME AND/OR PROGRAM TIME: THE HOUR – MINUTE – DAY ADVANCES AUTOMATICALLY IF NO BUTTONS ARE PRESSED AFTER 6 SECONDS

SETTING TIME

1. Press and hold down the [+] or [-] button for 3 seconds. The [HOUR] indicator will begin to flash. Press [+] or [-] to adjust the hour. Release the button when desired hour is reached.
2. Wait 6 seconds the [MINUTE] indicator will flash. Press [+] or [-] to adjust the minute. Release the button when desired minute is reached.

SETTING FEED TIME (1ST SETTING)

1. Press the [PROG] button. The first program indicator digit will begin to flash in the bottom left corner of the LCD display.
2. Press the [PROG] button again to navigate through the 1st program setting. The hour indicator will begin to flash. Press [+] or [-] to adjust the hour.
3. Press [PROG] to set the hour and advance to the [MINUTE] indicator. Press [+] or [-] to adjust the minute.
4. After set the time, press [PROG] to set the FEED RATE LENGTH. Press [+] or [-] to adjust the length from 1 to 30 seconds.

SETTING FEED TIMES 2-4 (FOR MULTIPLE FEEDINGS)

Repeat above steps. When all desired programs have been set wait 6 seconds and timer will return to normal time display.

CANCEL PROGRAM FEED TIME

1. Press [PROG] button and hold for 3 seconds. Press [+] or [-] to navigate to desired program cycle you want to cancel.
2. Press and hold the [PROG] button for 3 seconds until time display clears hour and minutes.
3. The timer will return to current time display after approximately 20 seconds.

TIMER RESET

Press recessed [R] button and hold for 3 seconds. All program cycle settings will be reset.

TEST

Press [TEST] button to activate test. USE CAUTION! There is a 5 second delay