



Bloodrunner™ II Instructions—The Best of Both Worlds

Closed Cutting Diameter = 1-1/8"

Open Cutting Diameter = 2-1/16"



Closed Broadheads

1. Remove the closed broadhead from the tray and insert into wrench (supplied).
2. Screw arrow shaft onto broadhead until tight.

Open Broadhead

1. Remove the OPEN broadhead from the packaging tray by holding the threads of the ferrule and CAREFULLY pull upwards. The broadhead will snap into the closed position.
2. Insert into supplied broadhead wrench.
3. Screw arrow shaft onto broadhead until tight.

HANDLE WITH EXTREME CAUTION

This product may be extremely dangerous and will cause injury if handled improperly. To avoid injury use the enclosed safety wrench when attaching and removing broadhead. Store heads in quiver after assembly.

ALSO AVAILABLE FROM NAP



Apache™ Drop-Away Arrow Rest

- > Tool-less adjustment & easy cord setup
- > Full containment, sound-deadened capture feature
- > Simple, rugged & reliable operation
- > Laser index marking
- > Self-centering, felt covered V-launcher
- > Right hand only



QuikFletch™ QuikSpin™ & Twister™ Vane System

- > Made of extremely tough materials for *maximum durability & long-lasting* performance.
- > *Won't come off* arrows, even on a game or target pass-thru
- > Easily replaced—*just slice & peel*—arrow stays clean.
- > Fletch 6 arrows in under 5 minutes with no tools or glue.