Trijicon DI Night Sight Fiber Install & Retainer Replacement Instructions



Cleaning Information

Normal cleaning will not degrade the sights. Avoid exposure to strong organic solvents when used in ultrasonic cleaning machines.

Fiber Installation Instructions

- Using T-10 Torque Key provided with your Trijicon DI Night Sight, unscrew the retainer ring located on the face of the front post by rotating it counterclockwise.
- Insert the pre-cut fiber replacement segment into the sight so that it is sitting against the back shelf of the sight.
- 3. Re-install the threaded retainer ring by rotating it clockwise until it is hand-tight.





Installation Tip

For best results, use Trijicon Dl™ replacement fibers. All fibers are finished using a proprietary technique to maximize day and nighttime brightness. Use of alternative fiber pieces could result in inferior performance of product.

Available Accessories

Standard Replacement Kit

AC50011 - Trijicon DI™ Night Sight Green Fiber & Black Retainer Replacement Pack

Available Fiber Replacement Packs

AC50010 - Trijicon DI™ Night Sight Fiber Replacement Pack - Green

AC50016 - Trijicon DI™ Night Sight Fiber Replacement Pack - Multicolor

Available Retainer Replacement Packs

AC50012 - Trijicon DI™ Night Sight Retainer Replacement Pack - White

AC50013 - Trijicon DI™ Night Sight Retainer Replacement Pack - Orange AC50014 - Trijicon DI™ Night Sight Retainer Replacement Pack - Yellow

AC50015 - Trijicon DI™ Night Sight Retainer Replacement Pack - Multicolor

Professional Installation Strongly Recommended for Mounting Sights to Firearm

