

MODEL N° 60013

OWNER'S MANUAL



_

2

BEFORE BEGINNING ASSEMBLY



Keep the hardware bags and their contents separate. If any parts are missing, call our Customer Service Department.



(x1)

TOOLS REQUIRED FOR THIS ASSEMBLY

Phillips Screwdriver Safety Glasses

(1 pair for each person)


ASSEMBLY GUIDES

Refer to the following areas throughout the instructions to assist in the assembly process:

This area is located at the top, left-hand corner of the page and indicates which tools and hardware are needed to complete the assembly steps on a page.



This area is located at the top, right-hand corner of the page and shows an image of the product with shaded parts indicating which section is being assembled.



This area is usually located in the bottom, left-hand corner of a step and indicates that special attention is needed to perform a particular part of a step.



These areas are usually located in the bottom, right-hand corner of a step and indicate that damage to the product or serious injury may occur if the caution or warning is not heeded.





Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are three-letter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.



ADZ (x10) 1/4" x 5/8" Pan-Head Screw

PARTS & HARDWARE LIST

ID Main F	Part	Description	Quantity
AYG AYL	Tool Corral Installation Hardware	Tool Corral	1
ADZ ADX	Tool oortal Installation Hartware	1/4" x 5/8" Phillips Pan-Head Screw #10 x 1/2" Phillips Pan-Head Screw	2 8

HARDWARE IDENTIFIER

TOOL CORRAL INSTALLATION HARDWARE [AYL]

Hardware shown at actual size




ADZ (x2) 1/4" x 5/8" Phillips Pan-Head Screw ✓




#10 x 1/2" Phillips Pan-Head Screw

PARTS IDENTIFIER

Part shown at 15% of actual size




Note: Throughout the Parts & Hardware List, Part & Hardware Identifiers, and instructions are threeletter IDs. These IDs are below the images of the parts and hardware to help you locate and identify the parts and hardware during assembly. These IDs are not necessarily on the parts themselves.



SEC 1.1

TOOL CORRAL INSTALLATION

The **Tool Corral (AYG)** can be placed in either the Left, Front or Right, Rear Corners of the Shed. Locate the screw bosses about one third of the way up the Panel and hold the Tool Corral so the holes in the ends line up with the screw bosses in the Wall Panel.



SEC 1.2

Attach both ends of the Tool Corral to the Corner Panel using the required hardware.

