



FOLDING KIDDIE KICK



OWNER'S MANUAL

**Read and understand this entire manual before
allowing child to use this product!**

Item Numbers:

Blue 13015040

Pink 13015061

SAFETY WARNINGS

⚠ WARNING: Riding the Folding Kiddie Kick can be a hazardous activity. Certain conditions may cause the equipment to fail without fault of the manufacturer. Like other wheeled products, the Folding Kiddie Kick can and is intended to move, and it is therefore possible to lose control, fall off and/or get into dangerous situations that no amount of care, instruction or expertise can eliminate. If such things occur, your child can be seriously injured or die, even when using safety equipment and other precautions. **USE COMMON SENSE.**

This manual contains many warnings and cautions concerning the consequences of failing to maintain, inspect or properly use your Folding Kiddie Kick. Because any incident can result in serious injury or even death, we do not repeat the warning of potential serious injury or death each time such a possibility is mentioned.

APPROPRIATE RIDER USE AND PARENTAL SUPERVISION

Direct adult supervision is required at all times. This manual contains important safety information. It is your responsibility to review this information and make sure that all children obey all warnings, cautions, instructions and safety topics and assure that young riders are able to safely use this product. Razor recommends that you periodically review and reinforce the information in this manual with young riders, and that you inspect and maintain your children's vehicle to insure their safety.

The recommended rider age of 3 years and older for Folding Kiddie Kick is only an estimate, and can be affected by the rider's size, weight or ability. Any child unable to fit comfortably on the Folding Kiddie Kick should not attempt to ride it.

A parent's decision to allow his or her child to ride this product should be based on the child's maturity, skill and ability.

DO NOT EXCEED THE WEIGHT LIMIT OF 45 pounds (20kg).

Rider weight does not necessarily mean a child's size is appropriate to fit or maintain control of the Folding Kiddie Kick.

Refer to the section on safety for additional warnings.

ACCEPTABLE RIDING PRACTICES AND CONDITIONS

Direct parental supervision is required. The Folding Kiddie Kick is meant to be used only in controlled environments free of potential traffic hazards and not on public streets. Do not allow your child to ride the Folding Kiddie Kick in any areas where vehicle traffic is present. Child must maintain a hold on the handlebars at all times. Never allow more than one child at a time to ride the Folding Kiddie Kick. Never use near steps, sloped driveways, hills, roadways, alleys or swimming pool areas. Keep fingers and other body parts away from the product when folding or unfolding. Adults must not allow children to assist in folding or unfolding the scooter.

Do not ride the Folding Kiddie Kick in wet weather. The Folding Kiddie Kick is intended for use on solid, flat, clean and dry surfaces such as pavement or level ground without loose debris such as rocks or gravel. Wet, slick or uneven and rough surfaces may impair traction and contribute to possible accidents. Do not ride the Folding Kiddie Kick in mud, ice, puddles or water. Avoid excessive speeds that can be associated with downhill rides. Never risk damaging surfaces such as carpet or flooring by use of a Folding Kiddie Kick indoors. Do not ride at night or when visibility is impaired.

PROPER RIDING ATTIRE

Always ensure child is wearing proper protective equipment such as an approved safety helmet. A helmet may be legally required by local law or regulation in your area. A child should always wear shoes, never ride barefooted or in sandals, and keep shoelaces tied and out of the way of the wheels.

FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS INCREASES RISK OF SERIOUS INJURY. USE WITH APPROPRIATE CAUTION AND SERIOUS ATTENTION TO SAFE OPERATION.

BEFORE YOU BEGIN

Remove contents from box and check parts against part diagram below. Remove the foam separators that protect the components from damage during shipping. Inspect the contents of the box for scratches in the paint or dents that may have occurred during shipping. Because the Kiddie Kick was partially assembled and packed at the factory, there should not be any problems, even if the box has a few scars or dents.


Estimated Assembly and Set-Up Time

Adult assembly required.


Allow up to 5–10 minutes for assembly.

No Tools Required.


WARNING: Keep fingers clear of the pivoting mechanism when folding or unfolding the Kiddie Kick. Do not allow children to fold or unfold this product.




SET-UP AND USAGE




1 Pull up the folding release lever to raise the front fork into the upright position.




2 Remove the "E" shaped fixed pin from the front fork assembly.




3 Slide the steering clamp cover onto the T-bar.



4 Insert the T-bar into the front fork assembly using your thumb to depress the button on the T-Bar until it "locks" into place.



5 Insert the "E" shaped fixed pin into the open hole on the front fork assembly to secure T-bar.



6 Slide the steering clamp cover down and over the "E" shape fixed pin.

KIDDIE KICK PARTS

Keep your Kiddie Kick running for years with genuine Razor parts.

- | | | | | | |
|---|--------------------------------|----|--------------------------------|----|-----------------------|
| 1 | Handlebar Grips | 6 | Spacer | 11 | Plastic Deck Bushing |
| 2 | T-Bar | 7 | Front Fork Assembly | 12 | Frame Assembly |
| 3 | Steering Clamp Cover | 8 | Tapping Screws-2 (Front Cover) | 13 | Deck |
| 4 | "E" Shape Fixed Pin | 9 | Front Cover | 14 | Folding Release Lever |
| 5 | Steering Bushing (Upper/Lower) | 10 | Phillip Screw - 4 (Deck) | | |

